



BASE FROM WALKER-ALASKA AERIAL SURVEY, INC., 1:12,000, 1988

SCALE 1:12,000
1000 0 1000 2000 3000 4000 5000 FEET
200 0 200 400 600 800 1000 1200 METERS

CONTOUR INTERVAL 20 FEET (BELOW 500 FEET)
CONTOUR INTERVAL 100 FEET (ABOVE 500 FEET)

PLATE 1. - MAP SHOWING DRAINAGE AREAS AND SURFACE WATER FLOW DIRECTIONS.

U.S. COAST GUARD SUPPORT CENTER
KODIAK, ALASKA