BASE FROM WALKER-ALASKA AERIAL SURVEY, INC., 1:12,000, 1988

SCALE 1:6,000

500 0 500 1000 1500 2000 2500 FEET

100 0 100 200 300 400 500 600 METERS

CONTOUR INTERVAL 10 FEET (BELOW 500 FEET)
CONTOUR INTERVAL 50 FEET (ABOVE 500 FEET)

PLATE 2. -- MAP SHOWING DRAINAGE AREAS AND SURFACE-WATER FLOW DIRECTIONS, NYMAN PENINSULA AND KODIAK AIRPORT AREA.

U.S. COAST GUARD SUPPORT CENTER

KODIAK, ALASKA

South Half